



## Threaded Locking Hitch Pin with Keys

Tools required:  
7/8" (21mm) wrench

### Instructions:

1. Place lock washer on bolt and slide bolt into holes. Hand Tighten.
2. Place lock over the opposite end of the bolt (making sure it is engaged) and place the dust cap over key hole.
3. Use 7/8" (21mm) wrench to tighten the bolt head to no more than 60ft lbs.
4. Periodically check the tightness of the bolt to ensure it is secure.

### Note:

A quality lock lubricant (preferably with graphite) is recommended for use at least once a year to best maintain the functionality of the lock. Simply add the lubricant to where the key enters the lock.

### Warning:

If this product is left on the receiver for long periods of time, the bolt may loosen slightly. Periodically check the tightness of the bolt and tighten if necessary.